Gabriel[®]

Gabriel internal test report for bleach cleanability

Test performed:	05. Oct. 2020
Test:	BIFMA HCF 8.1-2019 Health Care Furniture design guidelines or cleanability & ACT Test Method 1-2020
Bleach concentration:	1:10 Sodium Hypochlorite 5.25 – 6.25 %
Product tested:	2497/2501 Mica Dark – 97% post-consumer recycled polyester – 3% polyester

Gabriel tests all polyester fabrics, and tests include all colour options for each fabric. Tests are conducted in accordance with BIFMA's and ACT's recommended cleanability guidelines for use of cleaners, sanitisers and disinfectants on fabrics in hospitals and health care settings. The test result for each colour includes an assessment of the risk for colour change, when bleach is applied to the fabric in the concentrations required in health care environments.

When choosing a bleach-cleanable product, it is important to be aware that a variety of test methods to evaluate bleach resistance exist. Consequently, we recommend that you always ensure that the test method applied to a specific fabric meets the requirements - in terms of bleach concentration, application and contact time - for the specific context and environment in which the fabric will be used.

The test method applied by Gabriel is extremely thorough, and we consider it to be the best test available to assess and inform about the risk for colour change when using chlorine products.

Test description

1 ml of hospital grade disinfectant cleaner - diluted in accordance with the manufacturer's instructions - is applied to the centre of the test specimen. The solution is allowed to set for a period of two hours, after which any remaining liquids are blotted up (on both face and back).

The process is repeated for a total of ten times. Two hours after the 10th application, three ml of water are applied, excess fluids are blotted up with a clean white cloth, and the test specimen is allowed to air dry. The last step is repeated if chemical residue remains.

The material is evaluated by comparing the test specimen with AATCC Grey Scale for Color change.

Rating system – Grades according to AATCC Grey scale

Grade 5 – Very good-excellent Grade 4 – Good Grade 3 – Fair-moderate Grade 2 – Poor behaviour Grade 1 – Very poor

Acceptance criteria according ACT/BIFMA.

Colour Change:Grade 4 minimumColour Transfer:Not permittedPhysical damage:Not permitted

Gabriel[°]

Fabric	Colour	Name	Risk for colour changes*	Result
Mica Dark	60000	White	Low	5
Mica Dark	60002	Grey	Low	4-5
Mica Dark	60004	Light Grey	Low	4-5
Mica Dark	61008	Light Beige	Low	4-5
Mica Dark	62093	Light Yellow	Low	4-5
Mica Dark	64119	Red	Low	4-5
Mica Dark	66031	Light Blue	Low	4-5
Mica Dark	68145	Light Green	Low	4-5
Mica Dark	68146	Green	Low	4-5
Mica Dark	60021	Dark Grey	Low	4
Mica Dark	61011	Light Brown	Low	4
Mica Dark	62048	Green Yellow	Low	4
Mica Dark	62096	Yellow	Low	4
Mica Dark	64029	Dark Red	Low	4
Mica Dark	64146	Orange Red	Low	4
Mica Dark	66030	Blue	Low	4
Mica Dark	67015	Light Green	Low	4
Mica Dark	67042	Blue Green	Low	4
Mica Dark	62095	Brown Yellow	Medium	3-4
Mica Dark	64183	Light Red	Medium	3-4
Mica Dark	65112	Purple	Medium	3-4
Mica Dark	66006	Dark Blue	Medium	3-4
Mica Dark	66188	Violet	Medium	3-4
Mica Dark	67017	Dark Turquise	Medium	3-4
Mica Dark	67070	Green Blue	High	3

*) Low risk = Grade 4-5; Medium risk = Grade 3-4; High risk = Grade 3 and below

Gabriel A/S confirms that the above results were obtained after testing the specimen in accordance with the procedures and equipment specified above.

Gabriel A/S

hur hederaard

Kurt Nedergaard Director of CSR & Quality